









macsRemote - Connector LED Trouble shooting

Oranje LED	Grønn LED	Internett	Server
Konstant tent 	Raskt blinkende (3 blink pr. sek.) 	Tilkoblet	Ikke tilkoblet
Konstant tent 	Raskt blinkende (10 blink pr. sek.) 	Tilkoblet	Kobler til
Konstant tent 	Konstant tent 	Tilkoblet	Tilkoblet
Blinkende 	Konstant tent 	Mottar en oppdatering via trådløst nettverk	

